



**MPB3021AT**  
**MPB3032AT**  
**MPB3043AT**  
**MPB3052AT**  
**MPB3064AT**

**DISK DRIVES**

**MAINTENANCE MANUAL**

## REVISION RECORD

Edition	Date published	Revised contents
01	August., 1997	
02	March, 1998	All pages revised.

Specification No.: C141-F024-\*\*EN

The contents of this manual is subject to change without prior notice.

All Rights Reserved.  
Copyright © 1998 FUJITSU LIMITED



# PREFACE

This manual describes the MPB3021AT/MPB3032AT/MPB3043AT/MPB3052AT/MPB3064AT, a 3.5-inch hard disk drive with a BUILT-IN controller that is compatible with the IBM PC-AT interface.

This manual explains, in detail, how to maintenance the disk drives.

This manual assumes that users have a basic knowledge of hard disk drives and their application in computer systems.

This manual consists of the following two chapters:

**Chapter 1      MAINTENANCE AND DIAGNOSTIC**

**Chapter 2      REMOVAL AND REPLACEMENT PROCEDURE**

In this manual, disk drives may be referred to as drives, or devices.

IBM PC-AT is a registered trademark of IBM (International Business Machines Corporation) of the United States of America.

## Conventions for Alert Messages

This manual uses the following conventions to show the alert messages. An alert message consists of an alert signal and alert statements. The alert signal consists of an alert symbol and a signal word or just a signal word.

The following are the alert signals and their meanings:



This indicates a hazardous situation *likely* to result in *serious personal injury* if the user does not perform the procedure correctly.



This indicates a hazardous situation *could* result in *personal injury* if the user does not perform the procedure correctly.



This indicates a hazardous situation *could* result in *minor or moderate personal injury* if the user does not perform the procedure correctly. This alert signal also indicates that damages to the product or other property, *may* occur if the user does not perform the procedure correctly.



This indicates information that could help the user use the product more efficiently.

In the text, the alert signal is centered, followed below by the indented message. A wider line space precedes and follows the alert message to show where the alert message begins and ends. The following is an example:

(Example)



*The DE is completely sealed. Do not open the DE in the field.*

The main alert messages in the text are also listed in the “Important Alert Items.”

## **LIABILITY EXCEPTION**

"Disk drive defects" refers to defects that involve adjustment, repair, or replacement.

Fujitsu is not liable for any other disk drive defects, such as those caused by user misoperation or mishandling, inappropriate operating environments, defects in the power supply or cable, problems of the host system, or other causes outside the disk drive.



## Important Alert Items

### Important Alert Messages

The important alert messages in this manual are as follows:



A hazardous situation *could* result in *minor* or *moderate personal injury* if the user does not perform the procedure correctly. This alert signal also indicates that damages to the product or other property, *may* occur if the user does not perform the procedure correctly.

Task	Alert message	Page
Maintenance	<ol style="list-style-type: none"> <li>1. <i>Don't install or remove a PCA or connect or disconnect a cable or connector plug when the drive is powered. This may give you an electric shock.</i></li> <li>2. <i>Keep away from mechanical assemblies in the unit during operation. This may cause injuries.</i></li> <li>3. <i>Avoid dangerous detergents when cleaning the disk drive.</i></li> </ol>	1-1
	<ol style="list-style-type: none"> <li>1. <i>Before touching a PCA, perform the human body grounding to discharge static electricity from your body. This will prevent electrical damage to the PCA.</i></li> <li>2. <i>Don't install or remove a PCA or connect or disconnect a cable or connector plug when the drive is powered. This will prevent electrical damage to the disk drive.</i></li> <li>3. <i>Operating the disk drive with one or more PCA missing will be unpredictable. Only power the drive with all boards installed.</i></li> <li>4. <i>Avoid any detergent which may cause short circuits when cleaning assemblies.</i></li> <li>5. <i>Keep all vents open opened and unblocked. Avoid other conditions which may cause circuits to overheat.</i></li> <li>6. <i>A ribbon type cable has one line marked. Ensure that this line is always connected to pin 1 of the cable connector.</i></li> </ol>	1-2
	<i>The DE is completely sealed. Do not open the DE in the field.</i>	1-2
	<i>When asking for repair, save all data stored in the disk drive beforehand. Fujitsu Limited is not responsible for any loss of data during service and repair.</i>	1-3
	<i>The disk enclosure must never to opened in the field. Opening the disk enclosure may cause irreparable damage.</i>	1-12



Task	Alert message	Page
	<ol style="list-style-type: none"> <li data-bbox="570 310 1279 436">1. <i>Perform any removal after the system power is completely disconnected. The cable must not be disconnected and the screws that attach the drive must not be removed with the power ON.</i></li> <li data-bbox="570 453 1235 516">2. <i>Do not move the drive until it comes to a complete stop (about 30 s after the power is turned OFF).</i></li> <li data-bbox="570 533 1284 596">3. <i>Perform the human body grounding to discharge any static electricity from your body.</i></li> </ol>	2-2

# CONTENTS

	page
<b>CHAPTER 1 MAINTENANCE AND DIAGNOSIS</b> .....	1 - 1
1.1 Maintenance .....	1 - 1
1.1.1 Rules for maintenance .....	1 - 1
1.1.2 Maintenance requirements.....	1 - 2
1.1.3 Maintenance levels .....	1 - 5
1.1.4 Disk drive revision number .....	1 - 5
1.1.5 Tools and test equipment.....	1 - 7
1.1.6 Self-diagnostics .....	1 - 7
1.1.7 Test.....	1 - 7
1.2 Operation Confirmation.....	1 - 9
1.2.1 Operation test .....	1 - 9
1.2.2 Diagnostic test .....	1 - 10
1.3 Troubleshooting Procedure.....	1 - 10
1.3.1 Troubleshooting procedure.....	1 - 10
1.3.2 Troubleshooting disk drive replaced in field .....	1 - 10
1.3.3 Troubleshooting at factory.....	1 - 12
<b>CHAPTER 2 REMOVAL AND REPLACEMENT PROCEDURE</b> .....	2 - 1
2.1 Spare Parts .....	2 - 1
2.2 Disk Drive Removal .....	2 - 2



## FIGURES

	page
1.1 Disk drive revision number label.....	1 - 5
1.2 Display of disk drive revision number.....	1 - 6
1.3 Test flowchart.....	1 - 8

## TABLES

	page
1.1 Status register contents .....	1 - 9
1.2 Disposition for error register contents .....	1 - 9
1.3 System level and field troubleshooting.....	1 - 11
2.1 Model and parts numbers .....	2 - 2



# CHAPTER 1      MAINTENANCE AND DIAGNOSIS

- |  |
|--|
| <ul style="list-style-type: none"><li><b>1.1    Maintenance</b></li><li><b>1.2    Operation Confirmation</b></li><li><b>1.3    Troubleshooting Procedure</b></li></ul> |
|--|

This chapter describes the maintenance, diagnosis, operation check, and troubleshooting of the disk drive. The following are explained:

- Rules for regular maintenance and troubleshooting
- Display of maintenance level (field and factory)
- Display of machine revision number and number change in the field
- Tools and test devices needed for each maintenance level
- Standard testing for each maintenance level
- Recommended procedure for troubleshooting and fault diagnosis

## **1.1    Maintenance**

### **1.1.1    Rules for maintenance**

Obey the following rules to prevent injury during troubleshooting or maintenance.



1. *Don't install or remove a PCA or connect or disconnect a cable or connector plug when the drive is powered. This may give you an electric shock.*
2. *Keep away from mechanical assemblies in the unit during operation. This may cause injuries.*
3. *Avoid dangerous detergents when cleaning the disk drive.*

Obey the following rules for troubleshooting and maintenance to avoid damaging the disk drive.

## **CAUTION**

1. *Before touching a PCA, perform the human body grounding to discharge static electricity from your body. This will prevent electrical damage to the PCA.*
2. *Don't install or remove a PCA or connect or disconnect a cable or connector plug when the drive is powered. This will prevent electrical damage to the disk drive.*
3. *Operating the disk drive with one or more PCA missing will be unpredictable. Only power the drive with all boards installed.*
4. *Avoid any detergent which may cause short circuits when cleaning assemblies.*
5. *Keep all vents open and unblocked. Avoid other conditions which may cause circuits to overheat.*
6. *A ribbon type cable has one line marked. Ensure that this line is always connected to pin 1 of the cable connector.*

### **1.1.2 Maintenance requirements**

#### (1) Preventive maintenance

The disk drive needs no preventive maintenance, not even the air filter needs to be changed.

## **CAUTION**

*The DE is completely sealed. Do not open the DE in the field.*

#### (2) Service life

In situations where management and handling are correct, the life of the disk drive is five years when the DE surface temperature is less than 48°C. When the DE surface temperature exceeds 48°C, the life is five years or 20,000 hours of operation, whichever occurs first. For the measurement point of the DE surface temperature, refer to Section 3.2 in Product Manual.

(3) Exchangeable parts in field

The PCA and the DE cannot be replaced separately in the field. Replace the whole disk drive.

(4) Service system and repair

Fujitsu Limited has a disk drive service system and repair facility. When making a request for repair or parts replacement, you should provide related information usually including:

- a) Model name of disk drive, part number (P/N), disk drive revision number, manufacture serial number (S/N), and date of manufacture of the disk drive
- b) Circumstances when the fault occurred
  - Date of trouble occurred
  - System configuration
  - Environmental conditions (including temperature, humidity, and voltage)
- c) Fault history of the drive
- d) Details of the fault
  - Description of the fault
  - Issued command and specified parameters
  - Status (Status/Error register)
  - Interval of the fault
  - Other information for fault diagnosis



*When asking for repair, save all data stored in the disk drive beforehand. Fujitsu Limited is not responsible for any loss of data during service and repair.*

(5) Notes on handling

a. General notes

- a) Vibrations and shocks more severe than allowed will cause fatal damage to the device so be very careful. Be especially careful when unpacking the device.
- b) Do not leave the device in a dusty environment.
- c) Because the device uses static sensitive CMOS semiconductors take the following precautions, be careful of the handling on the following points after the device is unpacked.
  - Use an antistatic mat where the device is handled and it is recommended that the body of the handler be grounded.



- Hold by the DE section, do not directly touch the PCA unit unnecessarily.

b. Unpacking

- a) Use a flat workplace, find which side of the pack is up and be careful not to have the wrong side facing upwards. Do not place the device directly on a hard table, place it on something soft such as a rubber mat.
- b) Be careful not to apply any excessive force to the packed device when removing the shock absorbing material.
- c) When taking the device out of the antistatic bag, be especially careful not to apply any excessive force to the PCA or to the interface connector section.
- d) Never ever remove the DE seal label and screws and the DE cover.

c. Installation

- a) When the power is ON, do not change the switch setting, or connecting, or disconnecting connectors.
- b) Do not move the device or disconnect connectors with the power ON or until the disk drive unit comes to a complete stop after the power is turned OFF (about 30 seconds).

d. Packaging

- a) Place the device in an antistatic vinyl bag along with a desiccant (silica gel).
- b) It is recommended that you use the shock absorption cushion material and packaging that contained the device when it was delivered by Fujitsu.

If the same packaging material cannot be used, use a shock absorbent box that will transmit shocks directly to the device. When using this type of box, adequately protect the PCA surface and interface connector section.

- c) Place a label showing which side is up and clearly stating the notes on handling on the outside of the packaging.

e. Delivery

- a) As a rule, deliver as it is packaged and keep the up side up.
- b) If delivering a single drive after it is unpacked, take it only a short distance. Also, use shock absorbent material to protect it against shock and vibration. Deliver an unpacked device in either of the allowable packed positions. Refer to Section 3.2 in Product Manual.

f. Storage

- a) Store in dampproof packaging.
- b) Take care that the environmental requirements satisfy the non-operating environmental specifications described in Section 1.4 in Product Manual.
- c) To prevent condensation, do not subject the device to sudden changes of temperature.

**1.1.3 Maintenance levels**

Because of its compact size and special repair requirements, it is recommended that the whole disk drive be replaced. This section describes maintenance on two levels.

(1) Field maintenance (disk drive replacement)


- Replacement at the user site.
- Disk drive replacement requires ordinary tools.
- Usually, the user, retailer, seller, or OEM trader will replace the drive.

(2) Factory maintenance (parts replacement)

- Only Fujitsu can perform maintenance at this level.
- This includes maintenance training and assisting other OEM traders. The OEM trader usually assists the retailer and seller.
- Use the factory level tools and test equipment. This includes recommended spare parts and repairing or replacing various parts.

**1.1.4 Disk drive revision number**

The disk drive revision number is a single alphabetic character followed by a single alphanumeric character. It is stuck on the DE and marked on the revision number label. Figure 1.1 shows the disk drive revision number label format.



**Figure 1.1 Disk drive revision number label**

(1) Revision number marking at delivery

The machine revision number is indicated by crossing out up to the relevant number in the relevant alphabetic character row using = marks (see Figure 1.2).

(2) Revision number change in the field

When a part is replaced in the field or other modifications are made, the machine revision number may need to be changed. The level is indicated by crossing out the relevant number in the relevant alphabetic character row using O marks (see Figure 1.2).


(3) Firmware code and revision

First 2-digit indicates a firmware code and rest 2-digit indicates its revision.


**Note:**

For a change of revision number after delivery, Fujitsu issues a "Change Request/Notice" and the disk drive revision number after the change. When a change is made at the user site, the revision number level should be changed as described above.

Revision number mark when delivered



Revision number change in the field



**Figure 1.2** Display of disk drive revision number

### **1.1.5 Tools and test equipment**

At the field maintenance level, only ordinary hand tools are required for troubleshooting and repairing the disk drive. Special tools and test equipment is not required.

Factory level tools and test equipment are beyond the scope of this manual.

### **1.1.6 Self-diagnostics**

The disk drive has the following self-diagnostics. These self-diagnostics allow normal basic operation of an isolated disk drive can be checked.

- Initial self-diagnostics
- Offline self-diagnostics (EXECUTE DRIVE DIAGNOSTIC [DIAGNOSTIC] command)


### **1.1.7 Test**

The disk drive test can be divided into the following three levels.

- Operating test (See Subsection 1.2.1 on Operating test.)
- Diagnostic test (See Subsection 1.2.2 on Diagnostic test.)

Figure 1.3 shows the relationship between the test level and troubleshooting.

Tables 1.1 and 1.2 show the check contents.



**Figure 1.3 Test flowchart**

**Table 1.1 Status register contents**

Status bit	Contents
BIT0 = 1	Shown in Table 1.2
BIT1, 2	Normal
BIT3 = 1 BIT4 = 1 BIT5 = 1 BIT6 = 0 BIT7 = 1	(1) Check whether vibration is transmitted because of the way the disk drive is mounted. (2) Check the power, cable, and connector. (3) If it is concluded that the disk drive is the cause, replace the disk drive.

**Table 1.2 Disposition for error register contents**

Error bit	Method of disposition
BIT0, 4	(1) If an error occurs in a specific sector, treat that sector as a bad sector or replaced the sector. (2) If errors occur frequently, check for problems with the power supply and the mounting of the disk drive (disconnect the mainframe, power supply, and disk drive). (3) If it is concluded that the disk drive is the cause, replace the disk drive.
BIT1, 2	(1) Check the status of the host, cable, and drive. (2) If it is concluded that the drive is the cause, replace the drive.
BIT6	Process the bad sector.
BIT7	Avoid using the relevant track.

## **1.2 Operation Confirmation**

### **1.2.1 Operation test**

When the host computer is processing data, the disk drive monitors disk drive operation errors including data, command, and seek errors. The host is notified of the error that the disk drive detected and the user is notified of its result.

The user may notice intermittent and indefinite failures such as overlong execution time, abnormal noise, abnormal odor, or failures in particular processes.

The failure reported in the operation test will need further investigation. To ascertain the cause of the disk drive failure reported, the disk drive can be replaced. Failures in the operation test are often not caused by the host system. For example, not having enough power supply reserve, a loose cable connection, no timing and mechanical reserves, or relationship with other systems.

In normal operation, the disk drive itself or the host determines the processing (return or halt) following the detected failure state.

To troubleshoot the failure reported in the test at this level, accurately reproduce the condition that caused the failure. Then, by replacing the disk drive, try to separate the fault from the other sections of the disk drive host system.

### **1.2.2 Diagnostic test**

The diagnostic test is used to separate a confirmed disk drive failure to a disk drive subassembly or to check the disk drive performance. A test of this level usually includes a specific disk drive function or concentrated execution of a group of functions. The test is usually performed by a factory engineer and not where the failure was reported. The disk drive is tested using another host computer or test equipment.

To troubleshoot the disk drive failure in the diagnostic test, the engineer will reproduce the failure condition. The engineer then isolates the failure to a subassembly or part of the disk drive.

The procedures used in a test of this level great depend on the test equipment used. It is beyond the range of this manual.

## **1.3 Troubleshooting Procedure**

### **1.3.1 Troubleshooting procedure**

This section describes the troubleshooting procedures for a disk drive failure at field maintenance level described in Subsection 1.1.3.

In this section, troubleshooting is made to isolate the reported failure to the disk drive or a host system. Usually, troubleshooting is necessary only when a cause of failure is uncertain or unknown. When a cause of failure is clear (for example, abnormal sound in the DE or burnt parts on the PCA), a level of troubleshooting is low.

### **1.3.2 Troubleshooting disk drive replaced in field**

It is recommended that the whole drive be replaced in maintenance of this level. If replacing the drive corrects the fault, return the old drive to the factory for testing and repair. If the new drive shows the same fault as the one that was removed, the failure is elsewhere in the system.

System level troubleshooting, shown in Table 1.3, is performed at the user site to isolate the reported failure to the disk drive or system.

**Table 1.3 System level and field troubleshooting**

Check to be made	Recommended work
DC power cable	Confirm that the power cable is properly connected at the disk drive and power supply section.
DC power voltage level	<p>Confirm that the DC power voltage is within <math>\pm 5\%</math> (+5 VDC) or <math>\pm 8\%</math> (+12 VDC) of the standard value.</p> <p>When measured at pins 3 and 4 of the power supply connector, the +5 VDC must be 4.75 to 5.25 VDC.</p> <p>When measured at pins 1 and 2 of the disk drive power supply connector the +12 VDC must be 11.04 to 12.96 VDC.</p>
DC power ripple noise	Check that the maximum ripple at +5 and +12 VDC power is less than 100 mV peak to peak and 200 mV peak to peak respectively.
Interface cable connection	Confirm that the AT interface cable is properly connected at the disk drive and control unit.
Switch setting	Confirm that the switch on the switch on the disk drive control PCA is set for normal operation with the host computer. Refer to Section 3.4 in Product Manual for switching setting.
System cable	Confirm that all cable connections throughout the system correctly connected.
System diagnostic test	To further isolate the failure, if it can be done, execute the system level diagnostic routine described in the host computer manual.
Intermittent or indefinite error	<p>Check the AC voltage level at the power supply section and recheck the DC voltage level at the disk drive power supply connector.</p> <p>If the AC voltage level is abnormal, or if there is a lot of electrical noise, notify the user.</p> <p>If the DC voltage level is unstable, replace the power supply section.</p> <p>If possible, replace the disk drive. If the fault remains, the disk drive is not the case. For suggestions to isolate the failure further, refer to the hardware and software manuals provided with the system.</p>



### 1.3.3 Troubleshooting at factory

When the trouble is recovered by replacing the drive at field (Subsection 1.3.2), troubleshoot the replaced drive to isolate the trouble to the subassembly parts.

To shorten the troubleshooting time and repairing time, gather the data, such as environmental data and other information, from the user and then return the failed drive to the factory with the media defect list to repair.

At the factory, user environment is made and a reappearance test is performed. To reappearance a same trouble at user, the failed drive is connected to the host system. If no trouble occurs by the normal test, the reappearance test is performed by adding the voltage/temperature load using a disk drive tester or tools according to the user environment.

When a trouble reappeared, troubleshoot the cause of failure. Then, replace the failed unit or parts.

As this level maintenance is made by a factory, this maintenance level is beyond the scope of this manual.



*The disk enclosure must never to opened in the field. Opening the disk enclosure may cause irreparable damage.*

# CHAPTER 2      REMOVAL AND REPLACEMENT PROCEDURE

## 2.1    Spare Parts

## 2.2    Disk Drive Removal

This chapter explains the procedure for removing and replacing the disk drive. It is assumed that the reader has a thorough knowledge of replacing the complete disk drive and replacing the power-interface cable.

When carrying out these procedures, note the following items.

- The disk drive must have been removed from the host system.
- A power-interface cable to the disk drive must be disconnected.
- Mounting is done by reversing the steps for removal.

To carry out maintenance properly, observe the following:

- Place removed screws and other parts where they will not get lost or damaged.
- Keep a record of all maintenance work.
- Tighten screws securely but not excessively.
- Before touching the PCA, perform the human body grounding to discharge any static electricity from your body. This ensures that the worker will not electrically damage the PCA.

### 2.1    Spare Parts

See Table 2.1 for the model and parts numbers to order the replacement disk drive.

**Table 2.1 Model and parts numbers**

Model	Part Number	Formatted capacity	Mounting Screw
MPB3021AT	CA01630-B321	2162.76 MB	No. 6-32UNC
MPB3032AT	CA01630-B331	3243.66 MB	
MPB3043AT	CA01630-B341	4325.52 MB	
MPB3052AT	CA01630-B351	5249.66 MB	
MPB3064AT	CA01630-B361	6488.29 MB	

**2.2 Disk Drive Removal**

The method and procedures to dismount the disk drive to check the jumper terminal, change the jumper position, or replace the device differ depend on the system cabinet structure. Therefore, for actual working procedures, the specific conditions necessary for each system must be determined. The general removal procedures, with notes, is as follows.

- a) Disconnect the power-interface cable.
- b) Remove the screws that attach the drive and remove the drive from the system cabinet.
- c) When storing or transporting the drive, pack it an antistatic bag.

**Note:**

To protect the device from damage and prevent the worker getting hurt, observe the parts in Subsection 1.1.1 on Danger and Warnings.



- 1. *Perform any removal after the system power is completely disconnected. The cable must not be disconnected and the screws that attach the drive must not be removed with the power ON.*
- 2. *Do not move the drive until it comes to a complete stop (about 30 seconds after the power is turned OFF).*
- 3. *Perform the human body grounding to discharge any static electricity from your body.*



Comments concerning this manual can be directed to one of the following addresses:

FUJITSU LIMITED

Business Planning  
Solid Square East Tower  
580 Horikawa-cho, Saiwai-ku, Kawasaki,  
210-0913, Japan  
TEL: 81-44-540-4056  
FAX: 81-44-540-4123

FUJITSU COMPUTER PRODUCTS OF AMERICA, INC.

2904 Orchard Parkway, San Jose,  
California 95134-2009, U.S.A.  
TEL: 1-408-432-6333  
FAX: 1-408-432-3908

FUJITSU CANADA INC.

2800 Matheson Blvd. East, Mississauga, Toronto,  
Ontario L4W 4X5, CANADA  
TEL: 1-905-602-5454  
FAX: 1-905-602-5457

FUJITSU EUROPE LIMITED

2, Longwalk Road, Stockley Park, Uxbridge,  
Middlesex UB11 1AB, ENGLAND  
TEL: 44-81-573-4444  
FAX: 44-81-573-2643

FUJITSU DEUTSCHLAND GmbH

Frankfurter Ring 211, 80807 München, GERMANY  
TEL: 49-89-323780  
FAX: 49-89-32378100

FUJITSU NORDIC AB

Kung Hans Väg 12, S-192 68 Sollentuna, SWEDEN  
TEL: 46-8-626-6000  
FAX: 46-8-626-6711

FUJITSU ITALIA S.p.A.

Via Nazario Sauro, 38 20099 Sesto S. Giovanni (MI), ITALY  
TEL: 39-2-26294-1  
FAX: 39-2-26294-201

FUJITSU FRANCE S.A.

I, Place des Etas-Unis, SILIC 310,  
94588 Rungis Cedex, FRANCE  
TEL: 33-1-41-80-38-80  
FAX: 33-1-41-80-38-66

FUJITSU ICL ESPAÑA S.A.

Almagro 40, 28010 Madrid, SPAIN  
TEL: 34-1-581-8100  
FAX: 34-1-581-8125

FUJITSU AUSTRALIA LIMITED

2 Julius Avenue (Cnr Delhi Road) North Ryde N.S.W. 2113,  
AUSTRALIA  
TEL: 61-2-9776-4555  
FAX: 61-2-9776-4556

FUJITSU HONG KONG LTD.

Room 2521, Sun Hung Kai Centre, 30 Harbour Road, HONG  
HONG  
TEL: 852-2827-5780  
FAX: 852-2827-4724

FUJITSU KOREA LTD.

9th Floor, Korean Reinsurance Building, 80, Susong-Dong,  
Chongro-Gu, Seoul Special City, Republic of KOREA  
TEL: 82-2-739-3281  
FAX: 82-2-739-3294

FUJITSU COMPUTERS (SINGAPORE) PTE. LTD

20 Science Park Road #03-01,  
TELETECH PARK SINGAPORE SCIENCE PARK II,  
Singapore 117674  
TEL: 65-777-6577  
FAX: 65-771-5499

FUJITSU TAIWAN LTD.

8F, Hun Tai Center, 168-170, Tun Hwa North Road,  
1st Sec., Taipei, TAIWAN  
TEL: 886-2-545-7700  
FAX: 886-2-717-4644

FUJITSU SYSTEMS BUSINESS (MALAYSIA) SDN. BHD.

Fujitsu Plaza, 1A, Jalan Tandang 204, P.O. Box 636 Pejabat Pos  
Jalan Sultan  
46770 Petaling Jaya, Selangor Darul Ehsan, Malaysia  
TEL: 60-3-793-3888  
FAX: 60-3-793-0888

FUJITSU SYSTEMS BUSINESS (THAILAND) LTD.

12th Fl., Olympia Thai Tower, 444 Rachadapisek Road,  
Samsennok, Huay Kwang, Bangkok 10320, Thailand  
TEL: 66-2-512-6066  
FAX: 66-2-512-6068

